



Table of Contents

1	Product Description	2
1.1	Application	2
1.2	Mounting location	2
1.3	Characteristics	2
1.4	Function	2
2	Technical Data	3
3	Ordering Information	4
4	Description of Characteristics in Accordance with Type Code	5
4.1	Characteristic 1: Variant.	
4.2	Characteristic 2: Connection T torque control spring	
4.3	Characteristic 3: Connection V torque control spring	
4.4	Characteristic 4: Nominal volume flow	5
4.5	Characteristic 5: Pressure setting	
4.6	Characteristic 6: Damping	6
4.7	Characteristic 7: Setting Pressure valve output	6
5	Installation	7
5.1	General remarks	
5.2	Connection recommendations	7
5.3	Installation - space	7
5.4	Dimensions	
6	Notes, Standards and Safety Requirements	8
6.1	General remarks	
6.2	Standards	8
7	Accessories	8



Product Description

1.1 Application

WESSEL lowering brake check valves secure booms against unintentional extending and retracting of the cylinders during hose or pipe breaks. WESSEL lowering brake check valves are designed leakage-free and thereby hold the cylinder in a defined position. Multi-section booms, which are moved by cylinders, often tend to oscillate. In case of insufficient damping, oscillations can be caused by the control of a cylinder. Due to the excellent damping characteristics of these valves, vibration can almost be avoided.

Valves of variant 3N are designed as flangeable valves. They are mounted by means of four bolts directly onto the cylinder port to be protected.

1.2 Mounting location


The valve is installed onto the two cylinder connection of the boom that requires securing.

1.3 Characteristics

- Leakage free seat in hardened steel housing
- Load pressure independent opening of the control valve
- Cylinder tailored throttle cross sections of the control valve
- High damping characteristics
- Separate pressure limiting valve: Opening point is selectable independent of the DBV setting.
- Directly flanged to the cylinder

1.4 **Function**

In general, both cylinder connections are secured with a lowering brake valve type LHC. The hydraulic oil from the control valve flows via the check valve to the cylinder connection. The pressure rises since the opposite side is still closed off. As soon as the opening pressure for the lowering brake valve slide reaches the opposite side, it is opened and the oil can flow from the second cylinder chamber via the control valve to the tank. A path-dependent and direction-dependent dampening causes a vibration-free movement of the actuated cylinder. The pressure limiting valve is arranged parallel to the lowering brake valve slide. This can relieve in one embodiment to a separate tank connection, or in another embodiment to the control line.





2 Technical Data

Criterion	Units	Value	
Cylinder connection C		Ø11 – pmax < 450bar	
Max. operating pressure		450	
Max. volume flow	l/min	60	
Weight	kg	2.7	
Opening pressure of lowering brake valve		32 bar	
Connection			
T,V		see type code	
T1,V1		G 3/8, ISO 1179-1, T1 pmax < 10bar, V1 pmax < 350bar	
P G 1/4, ISO 1179-1, pmax < 350bar		G 1/4, ISO 1179-1, pmax < 350bar	
M		G 1/4, ISO 1179-1, pmax < 450bar	

Criterion	Units	Value	
Hydraulic fluid		Mineral oil (HL, HLP) conforming with DIN 51524, other fluids upon request	
Pressure fluid temperature range	°C	-20 – +80	
Ambient temperature:	°C	-30 – +50	
Viscosity range	mm²/s	2.8 – 500	
Contamination grade		Filtering conforming with NAS 1638, class 9, with minimum retention rate β₁₀≥75	

3 Or	dering Information			
LHC 00	3N 01 02	03 04 05	06 07	08
00	Product group	Load Control Valve Cylinder		LHC
01	Variant	Attachment with a hollow bolt on the cylinder connection		3N
	Connection T torque control spring		Closed	000
			AD16S	10R
02			AD12L	10F
"-			M14x1.5	01D
			G 3/8	03C
			G 1/4	03B
	Connection V torque control spring		Closed	000
			AD12S	10P
			AD6S	10M
03			AD12L	10F
			M14x1.5	01D
			G 3/8	03C
			G 1/4	03B
	Nominal volume flow		10 I/min	10
04		Layout of the control valve optimized for	20 I/min	20
04		the indicated volume flow	40 l/min	40
			60 I/min	60
05	Pressure setting	Opening/trigger point of the pressure limiting valve	>200 ≤450	XXX
06	Damping		Standard damping	01
30			High damping	02
	Pressure valve outlet to	Tank	T1, V1 closed, V, T open	T0
07		I alik	T1 closed, V, V1, T open	T1
07		Deturn line	T, T1, V1 closed, V open	V0
		Return line	T, T1 closed, V, V1 open	V1

XXX – permanently predetermined characteristics XXX – characteristics selectable by customer available onto available Different configurations are unfortunately not implementable for technical reasons. Please let us know if you have questions




4 Description of Characteristics in Accordance with Type Code

4.1 Characteristic 1: Variant

Mounting directly on the cylinder connection using 4 bolts.

4.2 Characteristic 2: Connection T torque control spring


The connection to the torque control spring can be selected in the following dimensions:




SW27 SW27 SW10 X 61

4.3 Characteristic 3: Connection V torque control spring


The connection to the torque control spring can be selected in the following dimensions:






4.4 Characteristic 4: Nominal volume flow

Indicates the recommended maximum volume flow from connection C (cylinder) to connection V or V1.



4.5 Characteristic 5: Pressure setting

Indicates the set opening start of the pressure limiting valve +/-5 bar. The value is permanently set and can not be changed. P (bar)







4.6 Characteristic 6: Damping


Using Code 01, the valve opens with the common nozzle damping.


With Code 02 a damping cartridge is installed that first shows a open lift area via a nozzle and thereafter a strong progressive damping. Closing the valve by removing the inlet pressure is always fast.

4.7 Characteristic 7: Setting Pressure valve output












5 Installation

5.1 General remarks


- Observe all installation and safety information of the construction machine manufacturer.
- Only technically permitted changes are to be made on the construction machine.
- The user has to ensure that the device is suitable for the respective application.
- Application exclusively for the range of application specified by the manufacturer.
- Before installation or dismantling, the hydraulic system is to be depressurized. Settings are to be made by qualified personnel only.
- May only be opened with the approval of the manufacturer, otherwise the warranty is invalidated.
- The included connection recommendations are not guaranteed. The functionality and the technical specifications of the construction machine must be checked.

5.2 Connection recommendations







G1/4 - 55Nm G3/8 - 80Nm M14x1,5 - 55Nm M18x1,5 - 90Nm



5.3 Installation - space

Attachment with a hollow bolt on the cylinder connection





6 Notes, Standards and Safety Requirements

6.1 General remarks

- The views in drawings are shown in accordance with the European normal projection variant
- A comma (,) is used as a decimal point in drawings
- All dimensions are given in mm



6.2 Standards

The following standards must be observed when installing and operating the valve:

- DIN EN ISO 13732-1:2008-12, Temperatures on accessible surfaces
- DIN EN ISO 13849 "Safety of machinery Safety related parts of control"
 - WESSEL-HYDRAULIK GmbH guarantees utilization of standard and proven safety principles in accordance with ISO 13849-2: 2003, Tables C.1 and C.2 for the construction of the valve described here.
 - WESSEL-HYDRAULIK GmbH has a certified quality management system in accordance with DIN EN ISO 9001.
 - The MTTFd value can be adopted from machine manufacturers with 150 years of experience for the described valve!
 - Note: The user is therefore responsible for complying with the fundamental and proven safety principles according to ISO 13849-2: 2003, Tables C.1 and C.2 for the implementation and operation of the hydraulic component!

7 Accessories